

BROTHER THREADING GUIDE

Universal Series / Template

1. UPPER THREADING

Raise the presser foot lever and turn handwheel toward you to raise the needle threader.

Place spool on pin; secure with spool cap. Pass thread through the rear guide.

DIAGRAM: SPOOL TO PRE-TENSION GUIDE

Follow the etched arrows down the right slot, around the U-turn, and up the left slot.

Hook thread through the Take-up Lever (right to left) and bring back down.

Pass thread behind the needle bar guide and thread the needle from front to back.

2. BOBBIN PLACEMENT (TOP-DROP)

Open bobbin cover. Insert bobbin so the thread unwinds in a "P" shape (counter-clockwise).

DIAGRAM: "P" ORIENTATION

Guide thread into the tension slit and follow the arrow path to the built-in cutter.

Maintenance Check: Always ensure the presser foot is UP while threading the upper path to allow tension discs to open. Clean bobbin area every 2-3 projects.

Print Chart