

THREADING REFERENCE

Portable Series v.1.0

Top Threading Path

TOP PATH DIAGRAM

- **1** Place thread on spool pin and secure with cap.
- **2** Pass thread through the rear guide hook.
- **3** Lead thread down into the tension disc groove.
- **4** Bring thread up and through the take-up lever.
- **5** Pass through the needle bar thread guide.
- **6** Thread needle from front to back.

Bobbin Installation

BOBBIN HOUSING DIAGRAM

- **1** Drop bobbin in so thread rotates counter-clockwise (P-shape).
- **2** Pull thread into the slit of the bobbin case.
- **3** Draw thread under the tension spring until it clicks.
- **4** Leave 4 inches of thread tail hanging out.

Check: Always raise the presser foot before threading the top path to ensure the tension discs are open.